

## Battery Charger Adapter Plate

7512

### For use with:

Blue Sea Systems' P12 Battery Chargers

7532, 7531

PROMARINER ProNauticP Series Battery Chargers

63150, 63160, 63180, 63110, 63115, 63120, 63130, 63140, 63170

### Before Installation

Test 7512 plate against open hole pattern on vehicle.

Any non-threaded hole on plate may be used for mounting.

Supplied holes are designed to fit industry standard patterns.

### Included Hardware

Qty 1 - 7512 Battery Charger Adapter Plate

Qty 4 - #10-32 x 0.75" Panhead Screws

Qty 4 - #10-32 Nylock Insert Nuts

## Installation Instructions

### Blue Sea Systems P12 Chargers

1. Install two #10-32 x 0.75" panhead screws from back of plate through the top mounting holes.

Minimum Torque: 10 in-lbs.

Maximum Torque: 25 in-lbs.

2. Mount the 7512 plate to the vehicle.

3. Hang charger from the two installed panhead screws.

4. Install two #10-32 Nylock nuts to secure charger to plate.

Do not fully torque down nuts yet.

5. Install two #10-32 x 0.75" panhead screws through the front of the charger's bottom mounting holes, into the plate and tighten.

Maximum Torque: 25 in-lbs.

6. Tighten the Nylock nuts on the top.

Maximum torque: 25 in-lbs.

7. Wire the charger per supplied instructions.

### ProMariner ProNauticP Chargers

1. Install four #10-32 x 0.75" panhead screws from back of plate through the indicated holes.

Minimum Torque: 10 in-lbs.

Maximum Torque: 25 in-lbs.

2. Mount the 7512 plate to the vehicle.

3. Hang charger from the four installed panhead screws.

4. Use four #10-32 Nylock nuts to secure charger to plate.

Tighten nuts in an X pattern.

Maximum Torque: 25 in-lbs.

5. Wire the charger per supplied instructions.

# Mounting Diagram

