

SHORE POWER CABLE SETS AND POWER CABLES INSTALLATION INSTRUCTIONS

USE

To minimize shock and fire hazard:

- Turn off the boat's shore connection switch before connecting or disconnecting the shore power cable sets or power cables.
- Connect shore power cable sets at the boat first.
- If the polarity warning indicator is activated , immediately disconnect the cable.
- Disconnect shore power cable sets at the shore outlet first.
- Close the cover of unused shore power inlets tightly.
- Do not alter shore power cable connectors.
- CS100IT4, CS75IT4, CW100IT4, CW125IT4 are connected for 250 VAC operation only, and CS75IT5, CS100IT5, CS125IT5, CW100IT5, CW125IT5, CW135IT5 are connected for 208 VAC operation only. The white neutral conductor was not installed in these cable sets and power cables. These are for use with ISOLATION TRANSFORMERS only.
- **Cord sets over 50 feet in length may present a drop in voltage that should be compensated for in specific applications.**

STORAGE

Store shore power cable sets indoors while not in use.

Use Hubbell closure caps cat. no. PC100 when cable sets or power cables are not plugged in.

MAINTENANCE

Disconnect cable from all power sources before performing any maintenance.

Spray contacts with electrical contact cleaner monthly (such as LPS-1 made by Holt Lloyd Corp., Tucker, GA).

Keep contacts and insulating surfaces free of contaminates.

Plugs whose contact pins are pitted or its housing is discolored and connectors with discolored housings should be replaced.

WARNING: This product contains chemicals, including lead, known to the state of California to cause birth defects or other reproductive harm. ***Wash hands after handling.***

