IC-M802

## GENERAL & EMAIL CONNECTION GUIDE

Components in shaded area only required for email

ICOM

SailMail

1. Download the SailMail application from *http://www.sailmail.com*.
2. Extract the zip file to the Desktop of your PC.
3. Double click the setup.exe file to begin the software installation.
4. Please refer the SailMail Primer *(http://www.sailmail.com/smprimer.htm)* for detailed instructions.

Cruise Email

1. Download the CruiseEmail application from *http://www.cruisemail.com*.
2. Extract the zip file to the Desktop of your PC.
3. Double click the setup.exe file to begin the software installation.
4. Please refer the CrusieEmail User Guide *(http://www.cruisemail.com)* for detailed instructions.

SP-24 EXTERNAL SPEAKER

M802 REMOTE HEAD *(RC-25)*

HF MARINE IC-M802

25W   USR
TRS
12A
27°25.299N
80°16.500W
Local 12:05   CALLING

GRIP   CH

OPC-1106

SCS Part #9090

SCS PTC-IIusb Pactor Modem *(Front)*

USB A/B Cable

DSP Multimode PACTOR Controller
SCS PTC-IIusb

M802 Transceiver Unit *(Front)*

SP   CONTROLLER   ACC

GPS   REMOTE   AF/MOD

From GPS (for DSC)

DC In   USB   TRX Control   GPS   TRX Audio

SCS PTC-IIusb Pactor Modem *(Back)*

SCS Part #8083

Tuner Control Socket

M802 Transceiver Unit *(Back)*

AT-140N Antenna Tuner

To Antenna

ICOM
AUTOMATIC ANTENNA TUNER
AT-140

ICOM

DC Power Socket

Antenna Connector 1

Coaxial Cable

OPC-1107A *(Power Cable)*

OPC-1147N *(Shielded Control Cable)*

To Battery

Copper Foil

RF Ground