



ADJUSTABLE BALL MOUNT KIT

Assembly & Installation
Instructions

PART NUMBER	33255
INSTALL TIME	5 MINUTES

DEALER / INSTALLER	Provide a copy of these instructions to the end user of this product. These instructions provide important operating and safety information for proper usage of this product. Demonstrate the proper use of the product with the end user. Have the end user demonstrate that they understand the proper use of the product.
---------------------------	--

END USER WARNING	Read and follow all instructions included in this manual. Ask your Dealer/Installer for assistance if you do not understand the proper use of the product. Never remove any decals from the product. Failure to follow these instructions can result in injury or death.
-------------------------	--

WARNING	DO NOT EXCEED Recommended towing limits. SEE VEHICLE'S OWNER'S MANUAL.
----------------	--

CONTENTS		33255 ADJUSTABLE BALL MOUNT KIT	33111 REPLACEMENT PINS FOR ADJUSTABLE BALL MOUNT
ITEM NO.	DESCRIPTION	QTY	QTY
1	SHANK	1	-
2	PIN	2	2
3	HAIR PIN *	3	2
4	2" / 2-5/16" BALL CASTING	1	-
5	RUBBER BUMPER	1	-
6	HITCH PIN **	1	-

US Patent #8,033,563 & 20200031185

* ONLY 2 HAIR PINS SHOWN IN PHOTO
** HITCH PIN NOT SHOWN IN PHOTO



WARNING	USE ONLY SUPPLIED HARDWARE TO INSTALL THIS KIT.
----------------	--

Disclaimer:

The ratings of the adjustable ball mount kit are intended to represent the capability of the product, and in no way reflect the ratings or capacity of the towing system it is being used with. You, the consumer or operator, are strongly advised to learn the ratings of the various components of the towing system and never exceed the limits of the lowest rated component being used.

The adjustable ball mount kit consists of two separate parts referred to as the Platform and the Dual Ball. The Platform included with this kit is rated for weight carrying up to 14,000 lbs. Gross Vehicle Weight Rating (GVWR) and up to 1,400 lbs. tongue weight.

The Dual Ball is rated up to 10,000 lbs. Gross Vehicle Weight Rating (GVWR) / 1,000 lbs. tongue weight when using the 2" ball, and 14,000 lbs. Gross Vehicle Weight Rating (GVWR) / 1,400 lbs. tongue weight when using the 2-5/16" ball.



WARNING: Do not exceed vehicle's towing capacity or receiver hitch capacity, whichever is less. See your Vehicle Owners Manual to determine Vehicle Tow Rating.

1. Install the Platform mount into the 2" receiver hitch of your vehicle and secure it with the included hitch pin and hair pin. Always secure the hitch pin with a hair pin unless a locking device is being used.
2. Determine which hitch ball size is to be used: 2" or 2-5/16". Once the approximate height for the ball installation has been determined, mate the dual ball to the platform by inserting the supplied clevis pins through the holes that line up with the holes in the platform. Secure the pins with the included hair pins. A patented pre-installed rubber bumper is installed in the dual ball to help prevent excessive rattles. During installation, some force may be required to push the dual ball in to position to allow the clevis pins to mate correctly.

NOTE:
The supplied pins are specifically engineered for the adjustable ball mount kit. If replacement pins are needed, they must be replaced with original factory adjustable ball mount kit pins.



WARNING: Use of any pin other than the pin supplied by Husky Towing could be a serious safety hazard and will void the warranty.

NOTES:

Prior to towing, check to make sure that the pins are secured into place with hair pins.

Never hook up trailer safety chains to the platform or ball.

The function of the pre-installed rubber bumper is to reduce rattles only.



WARNING: Please ensure that the safety chains operate freely around the adjustable ball mount kit and do not become entangled in the Platform or Dual Flange Ball.

RECOMMENDED PRODUCTS

Locking Pin Set - 33112

6.5 Ton Pintle Ball Combo - 33114

Adjustable Step Platform - 33257

10 Ton Pintle Ball Combo - 33258

WARRANTY TERMS

5 Year Limited Warranty:

The warranty applies to products used for individual and private use. Commercial usage of the product limits the warranty to one year from date of purchase.

What is covered by the warranty?

This warranty covers defects in materials and workmanship to the original purchaser for five years from the date of purchase. If the product is used for commercial use the warranty period is limited to one year from date of purchase.

The warranty does not cover:

Service or labor charges associated with the removal or replacement or return of this product.

Product finish (paint, chrome, etc.).

Product neglect, abuse, misuse or products involved in accidents or acts of God.

Improper use of this product (overloading or improper installation).

Any alterations to this product.

Wear/ Tear items such as the Rubber Bumper (anti-rattle component).

Procedure for warranty:

1. Contact the manufacturer at phone: 877-544-4449.
2. The original sales receipt from original owner must be provided during the Warranty/RMA Process.

If the product is found to be defective, the product may be repaired or replaced at the discretion of the manufacturer, owner shall be responsible for all transportation cost associated with the return of any products.

The manufacturer shall not be liable for any incidental or consequential damages, whether arising out of breach of contract or claimed defect in, or non-performance of the products.

This warranty gives you specific legal rights, and you may also have other legal rights that vary from state to state.